

INDICATORS AND CONTROLS

Instructions

Crown

- 1 To wind and set your watch, first unscrew the crown. Wind the watch by turning the crown forwards until you feel resistance. The movement and the chimes, driven from a single spring, are wound together.
- 2 To set the time, pull the crown to position 2 and turn it to bring the hands to the right time. The chime is blocked while you set the time.
- 3 **Note:** the crown must be screwed in for the watch to work.

Repeater button – at 2 o'clock.

Activate the minute-repeater by pressing the button right down and releasing it. The repeater will chime the hours, quarters and minutes.

Strike select button – at 4 o'clock.

Select grand strike, small strike or silent by pressing the button.

G = Grand strike: chimes the hours on the hour and with each quarter.

S = Silent: the chime is stopped.

P = Small strike (petite sonnerie): omits chiming the hours with each quarter.

Power-reserve indicator

- This shows the total amount of energy available for the movement, the chime in passing and the minute-repeater. To prevent the chimes using all the energy and stopping the watch, they are blocked to reserve the last 24 hours of power for the movement alone.
- If the chimes are silenced, the fully wound watch will keep going for 120 hours.

