



Manual winding:

Your watch is automatically wound when worn.

If the watch is stopped, turn the crown in position **1** about a dozen times clockwise.

The FFC offers a power reserve of 120 ± 12 hours.

Setting the time:

Pull the crown in position **2** and turn anti-clockwise to move the fingers and the minutes rotating dial.

A clutch system prevents clockwise time setting.

Important!

Push the crown back in position **1** for the watch to work.

On a rotating watch winder, program 274 rotations / 24 hours.
Turn only in the indicated direction!



Indication of the hours

