



1. Winding turn clockwise.
2. Moon setting turn anti-clockwise.
3. Time setting in both directions.

Warning
No moon setting between 11 am and 1 pm, and between 11 pm and 1 am.

Important!
Push the crown back in position 1 for the watch to work.

